

Doorlocks & Security on the Chrysler Sebring and Dodge Stratus 2001 & up (except Coupe)

On models equipped with a factory alarm system, you can use the LT.GREEN/ORANGE for both locks and security. A double pulse will be required to unlock the doors. For vehicles with no factory alarm, use the WHITE/GREEN for lock and unlock. Both wires are located in the C4 connector on the bottom of the BCM/Fusebox assembly under the driver's side dash.



NOTE: The information on this sheet is provided on an "as is" basis with no representation or warranty of accuracy whatsoever. It is the sole responsibility of the installer to check and verify any circuit before connecting to it. Only a computer safe logic probe or digital multimeter should be used. Wiremagic.com Corp. assumes absolutely no liability or responsibility whatsoever pertaining to the accuracy or currency of the information supplied. The installation in every case is the sole responsibility of the installer performing the work and Wiremagic.com Corp. assumes no liability or responsibility whatsoever resulting from any type of installation, whether performed properly, improperly or any other way. The information supplied is a guide only.