


## IGNITION INPUT WITH NEGATIVE KEYSWITCH OUTPUTS

Interfacing Ignition Inputs with Negative Keyswitch Outputs



**IMPORTANT!** This wiring information is being provided free of charge on an "as is" basis, without any representation or warranty. It is the dealer's responsibility to verify any circuit before interfacing with it using a digital multi-meter. Directed Electronics Inc. assumes no responsibility with regards to the accuracy or currency of this information. Proper installation in every case remains the responsibility of the installer.