

OMEGA MAX

Standard Features: The Omega MAX has it all! Incredibly fully-featured vehicle security with remote engine starting convenience. The MAX uses a window-mounted standard receiver module to ensure great operating range, and is also plug-in upgradable for the Echo 2-way pager/controller system. The MAX includes Omega's standard 6 and 3 pin harnesses, primary and secondary remote start harnesses, LED-CP-2 micro plug Red & Green Status Indicator Light, ZELC plug-in Valet Switch, and Omega's patented Psycho Siren. This unit has 4 remote start relays, flashing parking light and dome light relays all built-in. (-) negative doorlock outputs including driver door priority option, with basic harness. The MAX features patented Easy Valet and Selectable Coded Override operation. The MAX is fully compatible with Omega's GPS2000 Vehicle Notification, Control and Tracking system.

Security System w/ Remote Starting

Two Transmitters Included: 2 Black 4-Button Transmitters with soft-touch pictograph buttons, 433 MHz, code-jumping.

Operations: Lock Button - Press and release to Arm/Lock. Press and hold to activate Remote Panic with locking doors.

Unlock Button - Press and release to Disarm/Unlock. Press and hold to activate Remote Panic with unlocking the doors.

Remote Starting - Press and hold Lock and Unlock together.

Option Button - Press and hold to activate trunk release. Press and release twice to arm/lock - disarm/unlock without confirmation chirps.

Panic - Press and hold to activate remote panic, or change to 3rd Channel.

How to Code the Transmitters: Turn "on" the ignition, then press the valet switch 5 times and wait for siren confirmation of entry into programming mode. Press and release the Option transmitter button on each remote to be coded (one at a time). The system will respond to each with an audible confirmation.

Omega part
145-07



34 Programmable Features

FEATURE#	DEFAULT	LOCK	UNLOCK
Feature #1	1 & 0 switch presses (manual program)		
Feature #2	OFF	ON	OFF
Feature #3	OFF	ON	OFF
Feature #4	ON	ON	OFF
Feature #5	OFF	ON	OFF
Feature #6	OFF	ON	OFF
Feature #7	OFF	ON	OFF
Feature #8	OFF	ON	OFF
Feature #9	ON	ON	OFF
Feature #10	ON	ON	OFF
Feature #11	ON	ON	OFF
Feature #12	ON	ON	OFF
Feature #13	ON	ON	OFF
Feature #14	OFF	ON	OFF
Feature #15	60 Seconds	60 Seconds	30 Seconds
Feature #16	ON	ON	OFF
Feature #17	ON	ON	OFF
Feature #18	.8 Second	.0 Second	3 Seconds
Feature #19	OFF	ON	OFF
Feature #20	3 Seconds	3 Seconds	45 Seconds
Feature #21	Steady Siren	Pulsed Horn	Steady Siren
Feature #22	Medium Low	all 4 buttons used / 4 chirp levels	
Feature #23	OFF	ON	OFF
Feature #24	OFF	ON	OFF
Feature #25	OFF	ON	OFF